

Before Connecting



Warning

- 1) After unpacking, please check product and packing list first, if product is damaged or lack of parts, please contact with the local retailer;
 - 2) Before installation, be sure to cut off the grid power and make sure the battery is in the turned-off mode;
 - 3) Wiring must be correct, do not mistake the positive and negative cables, and ensure no short circuit with the external device;
 - 4) It is prohibited to connect the battery and AC power directly;
 - 5) The embedded BMS in the battery is designed for 48VDC, please DO NOT connect battery in series;
- 16BISV0903 04
- 6) Battery system must be well grounded and the resistance must be less than 1Ω ;
 - 7) Please ensured the electrical parameters of battery system are compatible to related equipment;
 - 8) Keep the battery away from water and fire.